



FORECLAD F200 ROOF PROFILES

- Main fixing through every trough and 2 continuous runs of 6x5mm or 9x3mm Butyl Mastic at sheet ends using self-drilling fasteners with sealing washers.
 - Intermediate fixings through every other trough.
 - Side Lap fixing at a maximum of 450mm centres with 1 continuous run of 6x5mm or 9x3mm Butyl Mastic using self-drilling fasteners with sealing washers.
-

FORECLAD F200 WALL CLADDING PROFILES

- Main fixing through every trough at sheet ends using self-drilling self-tapping primary fastener with sealing washers.
 - Intermediate fixings through every other trough.
 - Side Lap fixing at a maximum of 600mm centres using self-drilling fasteners with sealing washers.
-

FORECLAD F200 LINER PROFILES

- Main fixing through every trough at sheet ends and 1 continuous run of 50x1mm Polyband.
- Intermediate fixings through every other trough.
- Side Lap - A minimum of 1 continuous run of 50x1mm Polyband.

All information given on this page is intended to be used as a general guide only! Foregale will not be bound by the information and we reserve the right to make changes at any time.